#### \*\*\*READ ALL INSTRUCTIONS BEFORE USING\*\*\*

- For commercial use only.
- Warning: Risk of Injury Maximum load 275 lbs. 2 leg, 325 lbs. 3 leg
- Electrical rating: 120V, 60Hz, 16 AMP
- No more than 12 furnishings can be connected on one branch circuit.

#### IMPORTANT SAFETY INSTRUCTIONS

DANGER - To reduce risk of electric shock:


· Always unplug furnishing from the electrical out let before cleaning.

WARNING – To reduce the risk of burns, fire, electric shock, or injury to persons:

- Unplug from outlet before putting on or taking off parts.
- Close supervision is necessary when this furnishing is used by, or near children, invalids or disabled persons.
- Use this furnishing only for its intended use as described in these instructions. Do not
  use attachments not recommended by the manufacturer.
- Never operate this furnishing if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water.
- · Keep the cord away from heated surfaces.
- Never operate the furnishing with the air openings blocked. Keep the air openings free of lint, hair and the like.
- Do not use outdoors.
- To disconnect, turn all controls to the off position, then remove plug from outlet.
- Connect to a properly grounded outlet only. See grounding instructions.
- For loading always put heavier items at the bottom and not near the top in order to help prevent the possibility of the furnishing tipping over.




# Wiring Schematic



#### **GROUNDING INSTRUCTIONS**

This product is for use on a circuit having a nominal rating more than 120 volts and is factory-equipped with specific electric plug to permit connection to a proper electric circuit. Make sure that the product is connected to an outlet having the same configuration as the plug. No adapter should be used with this product





www.ais-inc.com

#### Hardware List

<b>ADMINITION</b>	 Flat head wood screw #9 x 7/8 long with #2 Phillips drive, silver Used to attach surfaces and end panels	
	 Hex cap machine screw ½-20 x 5/16" long with 3/16" hex drive, black Used on leg assembly and rail assemblies	
	 Hex cap machine screw ¼-20 x 5/8" long with 3/16" hex drive, black Used on spine beam mounts and cable tray	
	 Hex set screw 3/8-16 x 1/2" long with 3/16" hex drive, black Used on rail mount and spine beam mounts	
	 Hex set screw $\frac{1}{4}$ -28 x 1/4" long with 1/8" hex drive, silver Used on spine screens	
E MANAGE	 Pan head machine screw 10-24 x $5/8$ " long thread cutting tip with #2 Phillips drive, silver. Used to attach outlets.	
	 Pan head machine screw 8-32 x 3/8" long thread rolling tip with #2 Phillips drive, silver. Used to assemble electrical covers.	
	 Pan head machine screw 10-32 x $1/2$ " long with #2 Phillips drive, silver. Used on spine screens to attach base support brackets.	
	 Flat head machine screw 10-32 x 1/2" long with #2 Phillips drive, silver. Used on territory screens to attach base support brackets.	
	 Pan head machine screw 8-32 x 1/4" long with #2 Phillips drive, silver. Used with acorn nuts to attach powerpole.	
	 Acorn nut 8-32 x $5/16$ " long, silver. Used with 8-32 x $1/4$ " long screws to attach powerpole.	
	Pan head drill point sheet metal screw #8 x 3/8ths" long with #2 Phillips drive, silver. Used to attach Side Mount screens to hanging brackets and endcap worksurface cantilevers to legs.	
A Managaman	 Flat head sheet metal screw #8 x 2" long with #2 Phillips drive, silver. Used to mount Endcap Hutch to base.	
E MINIME	 Flat head sheet metal screw #10 x 3/4" long with #2 Phillips drive, silver. Used to mount items to laminate storage cabinets.	


Date	Page No.	Description of change	Name
2/11/19	1-49	Released	S. Powers
3/7/19	49-54	Added modesty and end panel instructions	S. Powers



#### Fixed Height Assembly


#### Note:


Installation instructions for Fixed Height Leg and Motorized Leg are the same. Images on the following pages are showing installation of a Motorized Leg.







#### Single Bench Base Assembly








Make sure set screw tips DO NOT protrude past inside wall of collars.















Slide compression collar over base column to top, set screws facing as shown. Be careful not to scratch base columns.




#### Single Bench Base Assembly














#### Single Bench Base - End Legs









alignment holes in

plate.

Be sure angled lip on spine beam arm assembly rests on outer column top





both columns clamping arm to columns.






#### Double/Triple Bench **Base Assembly**






Set

Motorized, Crank or Fixed **Height Leg** 



Make sure set screw tips DO NOT protrude past inside wall of collars.







Slide compression collars over base columns to top, set screws facing as shown. Be careful not to scratch base columns.




### Double/Triple Bench Base Assembly








#### Double/Triple Bench Base Assembly







#### Double/Triple Bench Base Assembly



Slide arm assembly down in between columns.









# Outlet & Powerway Cover Installation

36w – 96w Powered Spine Beam Assembly (Shown on floor upside down)



10-24 x 5/8" Pan Head
Machine Screw with thread
cutting tip, 1 per outlet in
bottom hole

Insert numbered outlets per plan, engaging left or right as shown. Then screw outlets to powerway to secure.








Note: Overlap flanges such that small holes are "behind" big holes.



#### Wire Basket Installation











### Single Bench Spine Beam Assembly







### Single Bench Spine Beam Assembly









# Aloft 120 - 2019 Double Bench - Spine Beam Assembly







www.ais-inc.com




www.ais-inc.com


### Triple Bench-Spine Beam Assembly









# Spine Beam Assembly – Double/Triple Bench Bracket













www.ais-inc.com

#### Worksurface Installation




# Single Bench Cross Brace sizes 54-96 only



#### Notes:

- Install Cross Braces after worksurfaces have been installed.
   Worksurfaces and spine beams not shown here for clarity.
- Install left and right cross braces on bench sizes 54 – 96 only




# Single Bench Cross Brace sizes 54-96 only

Twist plate

#### Notes:

- Secure left and right cross braces to spine beam on both ends using twist plates and ¼-20 x 5/8" long hex cap screws.
- · Worksurfaces not shown here for clarity.
- Install left and right cross braces on bench sizes 54 – 96 only.






3/16" hex drive


black, x2

# Double Bench Cross Brace sizes 54-96 only



#### Notes:

- Install Cross Braces after worksurfaces have been installed. Worksurfaces and spine beams not shown here for clarity.
- Install left and right cross braces on bench sizes 54 – 96 only




# Double Bench Cross Brace sizes 54-96 only

Twist plate

#### Notes:


- Secure left and right cross braces to spine beam on both ends using twist plates and ¼-20 x 5/8" long hex cap screws.
- · Worksurfaces not shown here for clarity.
- Install left and right cross braces on bench sizes 54 – 96 only.






1/4-20 x 5/8" long 3/16" hex drive


black, x2






Align this edge with Cantilever edge so that the trough is offcentered from the worksurface








### Jumper Installation





#### Motor Controller Installation





#### Motor Controller Installation









www.ais-inc.com


#### Hand Switch Installation




### Wire Manager Installation





#### Power Cord Installation














# Aloft 120 - 2019 Glass Territory Screen Assembly Handed Glass Screen Rail Assembly (Right Hand Shown) **Bracket Bracket** #10-32 x 5/16" Flat Head Machine Screw 4 Places

**OX-SLSCBM** 

 Screw must not protrude beyond rail inner surface




# Glass Territory Screen Assembly




- Insert polycarbonate spacers (3 places) down in between glass screen and rail so that the spacer is located on the side directly behind the set screw holes.
- Install set screws (3 places), tightening to polycarbonate spacers. Check to insure set screw is not touching the glass surface and is flush or below the rail surface. (see image below)
- Glass screen should be secure to rail with no wobble.


Flush surface required






Set Screw 1/4-28 x 1/4" 3 places






# Left or Right Screen Install (same for glass or framed)








www.ais-inc.com


#### Glass Spine Screen Install

Install Glass into Channel Mount






- Insert polycarbonate spacers (3 places) down in between glass screen and rail so that the spacer is located on the side directly behind the set screw holes.
- Install set screws (3 places), tightening to polycarbonate spacers. Check to insure set screw is not touching the glass surface and is flush or below the rail surface. (see image below)
- Glass screen should be secure to rail with no wobble.






#### Glass Spine Screen Install


### **End Cap Installation**




 If necessary, shave excess paint on tabs to insure end cap is properly seated.

### Rail Cover Installation








 Tap gently using soft mallet until end cap is properly seated. DO NOT break tabs.



#### Rail Cover

 Snap rail cover down onto rail from above using block of wood with soft mallet.




 Insure Rail Cover is properly seated






#### Tackable Spine Screen Install




www.ais-inc.com

#### Single Bench Modesty Installation





Top View
Position modesty as
shown when end
panels are required




Top View
Position modesty as
shown when ganging
benches or when no end
panels are required




-- or --

### Single Bench Modesty Installation











#### **Double Bench Modesty Installation**





Top View
Position modesty as
shown when end
panels are required




Top View
Position modesty as
shown when ganging
benches or when no end
panels are required





-- or --

#### **Double Bench Modesty Installation**



#### **End Panel Installation**







\*\*\*SAVE THESE INSTRUCTIONS\*\*\*

