

Granite™

Task Chair User Instructions



1. Back / Lumbar Support
2. Height Adjustable Arms
3. Upright Back Lock
4. Seat Height Adjustment
5. Back Tension Adjustment

1. Back / Lumbar Support:

Automatic back support adjustment based on your body contouring. Granite was engineered with a body conforming lumbar support as well as a height adjustable lumbar support element.

Benefits of Back / Lumbar Support:

Proper back support allows you to maintain a natural and comfortable curvature of the back. The Granite provides for a self-adjusting and fitting level of personalized lower (lumbar), middle and upper back support through the passive responsive fitting of the mesh back shape to the user's back.

2. Height Adjustable Arms:

Raise or lower the arms to the desired height by pushing the button located on the outside of the arm post for fitting and comfortable support.

Benefits of the Height Adjustable Arms:

Most office chairs have armrests that allow a user to occasionally rest their arms while sitting. For many tasks the provision of arm support can reduce upper body fatigue, allow for easier shifts in body position when sitting, and make it much easier to enter and exit the chair. Armrests help to decrease body flexion, knee and hip movements, thereby reducing stress in the knee and hip joints during sitting-to-standing transitions, which is an especially important consideration for an aging workforce. Granite arms are height adjustable allowing you to comfortably support forearms or elbows on the generously sized soft arm-caps while sitting with your shoulders relaxed. The armrests should not interfere with access to the work-surface or any other chair adjustments.

3. Upright Back Lock:

Lock the back in the upright position by pushing the handle located under the right hand side of the seat inward (same handle used for seat height adjustment). Unlock the back by releasing your weight from the back and pulling the handle outward.

Benefits of the Upright Back Lock:

Locking the chair back is contrary to the need for movement and unnecessary when the back tension is properly set allowing for balanced resistance. The upright back lock is offered to accommodate possible task needs and personal preferences.

4. Seat Height Adjustment:

Adjust the seat height by lifting the lever located under the right hand side of the seat. Once adjusted you should have your feet flat on the floor with your upper to lower legs at approximately 90°.

Benefits of the Seat Height Adjustment:

With your body all the way back in the seat you should experience the full support of the seat for hips, posterior and thighs with little to no pressure under the front of the thigh (waterfall seat cushion). Undue pressure in turn may hamper blood circulation in lower legs potentially causing an ache, pain or injury. The Granite seat provides comfort through generously dimensioned high quality molded seat foam allowing for precise weight distribution and support.

5. Back Tension Adjustment:

Adjust the tension by rotating the knob located in the middle under the seat. Rotate the knob counter clockwise to increase and clockwise to decrease the back tension as needed to allow for comfortable support as well as back and forth movement.

Benefits of the Back Tension Adjustment:

Tension adjustment allows for the reclining back resistance to fit your shape, size and preference. Once properly adjusted the tension setting should allow for balanced resistance and freedom to lean forward and back. Balanced resistance: the chair will remain in the chosen reclined position without you having to use any muscle groups- the chair works for you rather than you working for the chair.